VALVE TERMINALS SIZING CHART

| Valve terminal | Position of D-Sub Connector | Valve width | 3 or 5 way valves | Number of stations | Cv required | Valves | Description of assembly | Terminal Part Number |
|--|--|-------------------|-------------------|--|-------------|--|---|----------------------|
| Valve Terminal (coil pins inserted in electric rail, inlet is D-Sub connector) "T" = Valve Terminal | Connector | | | | | MD 311 104 T, normally closed, port 2 in plate (M5), coil pins form C, 0.03 Cv (page 82) | 3/2 valves, air supply port 1 (G1/8"), | T_ 16 3 104 |
| | "R" = right end side "L" = left hand side | | 3way | From 02 to 14 | 0.03 | MD 311 104 L T, normally closed, port 2 in plate (pif 4mm), coil pins form C, 0.03 Cv (page 82) | exhaust in coil tube (threaded M3) | T_ 16 3 144 |
| | | | | | 0.3 | MD 310 343 T, normally closed, port 2 in valve (pif 4mm), 0.3 Cv (page 85) | 3/2 valves, air supply port 1 and exhaust port 3 (G1/8") | T_ 16 3 303 |
| | | | | | | MOD 310 343 T, normally open, port 2 in valve (pif 4mm), 0.3 Cv (page 85) | | |
| | | | | | 0.5 | MD 310 403 T, normally closed, port 2 in valve (G1/8"), 0.5 Cv (page 85) | 3/2 valves, air supply port 1 and exhaust port 3 (G1/4") | T_ 16 3 403 |
| | | | | | | MD 310 463 T, normally closed, port 2 in valve (pif 6mm), 0.5 Cv (page 85) | | |
| | | | | | | MOD 310 403 T, normally open, port 2 in valve (G1/8"), 0.5 Cv (page 85) | | |
| | | | | | | MOD 310 463 T, normally open, port 2 in valve (pif 6mm), 0.5 Cv (page 85) | | |
| | | | | | 0.3 | MD 310 304 T, normally closed, port 2 in plate (pif 4mm), 0.3 Cv (page 86) | 3/2 valves, all ports in plate, air supply port 1 and exhaust port 3 (G1/8") | T_ 16 3 344 |
| | | | | | | MOD 310 304 T, normally open, port 2 in plate (pif 4mm), 0.3 Cv (page 86) | | |
| | | | | | 0.5 | MD 310 404 T, normally closed, port 2 in plate (pif 6mm), 0.5 Cv (page 86) | 3/2 valves, all ports in plate, air supply port 1 and exhaust port 3 (G1/4") | T_ 16 3 464 |
| | | | | | | MOD 310 404 T, normally open, port 2 in plate (pif 6mm), 0.5 Cv (page 86) | | |
| | | | 5way | From 02 to 14 (double solenoid valves use 2 positions) | 0.3 | MD 510 303 T, 5/2way, ports 1, 2 & 4 (M5), 0.3 Cv (page 101) | 5way, ports 2 & 4 on valve and ports 1, 3 & 5 in plate, air supply port 1 and exhaust ports 3 & 5 (G1/8") | T_ 16 5 303 |
| | | | | | | MD 510 343 T, 5/2way, 1, 2 & 4 (pif 4mm), 0.3 Cv (page 101) | | |
| | | | | | | MD 520 303 T, 5/2way, double solenoid, ports 1, 2 & 4 (M5), 0.3 Cv (page 105) | | |
| | | | | | | MD 520 343 T, 5/2way, double solenoid, ports 1, 2 & 4 (pif 4mm), 0.3 Cv (page 105) | | |
| | | | | | | MD 53_ 303 T, 5/3way, double solenoid, ports 1, 2 & 4 (M5), 0.3 Cv (page 114) | | |
| | | | | | | MD 53_ 343 T, 5/3way, double solenoid, ports 1, 2 & 4 (pif 4mm), 0.3 Cv (page 114) | | |
| | | | | | 0.5 | MD 510 403 T, 5/2way, port 1 (4mm), ports 2 & 4 (G1/8"), 0.5 Cv (page 101) | 5way, ports 2 & 4 on valve and ports 1, 3 & 5 in plate, air supply port 1 and exhaust ports 3 & 5 (G1/4") | T_165403 |
| | | | | | | MD 510 463 T, 5/2way, port 1 (4mm), ports 2 & 4 (pif 6 mm), 0.5 Cv (page 101) | | |
| | | | | | | MD 520 403 T, 5/2way, double solenoid, port 1 (4mm), ports 2 & 4 (G1/8"), 0.5 Cv (page 105) | | |
| | | | | | | MD 520 463 T, 5/2way, double solenoid, port 1 (4mm), ports 2 & 4 (pif 6mm), 0.5 Cv (page 105) | | |
| | | | | | | MD 53_403 T, 5/3way, double solenoid, port 1 (4mm), ports 2 & 4 (G1/8"), 0.5 Cv (page 114) | | |
| | | | | | | MD 53_463 T, 5/3way, double solenoid, port 1 (4mm), ports 2 & 4 (pif 6mm), 0.5 Cv (page 114) | | |
| | | | | | 0.3 | MD 510 304 T, 5/2way, ports 1, 2, 3, 4 & 5 (3mm), 0.3 Cv (page 103) | 5way, all ports in plate, 2 & 4 (pif 4mm), air supply port 1 and exhaust ports 3 & 5 (G1/8") | T_ 16 5 344 |
| | | | | | | MD 520 304 T, 5/2way, double solenoid, ports 1, 2, 3, 4 & 5 (3mm), 0.3 Cv (page 107) | | |
| | | | | | | MD 53_ 304 T, 5/3way, double solenoid, ports 1, 2, 3, 4 & 5 (3mm), 0.3 Cv (page 116) | | |
| | | | | | 0.5 | MD 510 404 T, 5/2way, ports 1, 2, 3, 4 & 5 (4mm), 0.5 Cv (page 103) | 5way, all ports in plate, 2 & 4 (pif 6mm), air supply port 1 and exhaust ports 3 & 5 (G1/4") | T_ 16 5 464 |
| | | | | | | MD 520 404 T, 5/2way, double solenoid, ports 1, 2, 3, 4 & 5 (4mm), 0.5 Cv (page 107) | | |
| | | | | | | MD 53_404 T, 5/3way, double solenoid, ports 1, 2, 3, 4 & 5 (4mm), 0.5 Cv (page 116) | | |
| | | "22" = 22 mm wide | 3way | From 02 to 12 (others on request) | 1.3 | MK 310 703 T, normally closed, port 2 in valve (G1/4"), 1.3 Cv (page 77 see MH 310 701 G) | 3/2 valves, air supply port 1 and exhaust port 3 (G3/8") | T_ 22 3 703 |
| | | | | | | MOK 310 703 T, normally open, port 2 in valve (G1/4"), 1.3 Cv (page 77 see MOH 310 701 G) | | |
| | | | 5way | From 02 to 12 (others on request) (double solenoid valves use 2 positions) | 0.7 | MK 510 503 T, 5/2way, port 1 (4mm), ports 2 & 4 (G1/8"), 0.7 Cv (page 102 see MH 510 503) | H | T_ 22 5 503 |
| | | | | | | MK 520 503 T, 5/2way, double solenoid, port 1 (5mm), ports 2 & 4 (G1/8"), 0.7 Cv (page 106 see MH 520 503) | | |
| | | | | | | MK 53_503 T, 5/3way, double solenoid, port 1 (5mm), ports 2 & 4 (G1/8"), 0.7 Cv (page 115 see MH 53_503) | | |
| | | | | | 1.3 | MK 510 703 T, 5/2way, port 1 (7mm), ports 2 & 4 (G1/4"), 1.3 Cv (page 102 see MH 510 703) | exhaust ports 3 & 5 (G1/4") | T_ 22 5 703 |
| | | | | | | MK 520 703 T, 5/2way, double solenoid, port 1 (7mm), ports 2 & 4 (G1/4"), 1.3 Cv (page 106 see MH 520 703) | | |
| | | | | | | MK 53_ 703 T, 5/3way, double solenoid, port 1 (7mm), ports 2 & 4 (G1/4"), 1.3 Cv (page 115 see MH 53_ 703) | | |
| | | | | | 0.7 | MK 510 504 T, 5/2way, ports 1, 2, 3, 4 & 5 (5mm), 0.7 Cv (page 104 see MH 510 504) | 5way, all ports in plate, 2 & 4 (G1/8"), air supply port 1 and exhaust ports 3 & 5 (G1/4") | T_ 22 5 504 |
| | | | | | | MK 520 504 T, 5/2way, double solenoid, ports 1, 2, 3, 4 & 5 (5mm), 0.7 Cv (page 108 see MH 520 504) | | |
| | | | | | | MK 53_504 T, 5/3way, double solenoid, ports 1, 2, 3, 4 & 5 (5mm), 0.7 Cv (page 117 see MH 53_504) | | |
| | | | | | 1.3 | MK 510 704 T, 5/2way, ports 1, 2, 3, 4 & 5 (7mm), 1.3 Cv (page 104 see MH 510 704) | 5way, all ports in plate, 2 & 4 (G1/4"), air supply port 1 and exhaust ports 3 & 5 (G3/8") | T_ 22 5 704 |
| | | | | | | MK 510 704 T, 5/2way, double solenoid, ports 1, 2, 3, 4 & 5 (7mm), 1.3 Cv (page 108 see MH 520 704) | | |
| | | | | | | MK 53_704 T, 5/3way, double solenoid, ports 1, 2, 3, 4 & 5 (7mm), 1.3 Cv (page 117 see MH 53_704) | | |
| | | | | | | Same valves as above (MK 510 704 T, MK 510 704 T and MK 53_ 704 T). | 5way, all ports in plate, 2 & 4 (pif 8mm), air supply port 1 and exhaust ports 3 & 5 (G3/8") | T_ 22 5 784 |

All coils are 16mm wide, 1.8 Watt / 3 VA solenoid. Every station is equipped with a varistor and red LED for coils 24V DC.